








# 1



# 2







Android™ iPhone








WH-CH500




# 3





Android



[http://rd1.sony.net/help/mdr/whch500/h\\_zz/](http://rd1.sony.net/help/mdr/whch500/h_zz/)

